



- Notes:
1. Isolation Joints Should be at least  $\frac{1}{2}$ " Wide and Filled With a Compressible Material
  2. Boxouts Should be Large Enough to Provide at Least 1ft. Clearance Between the Fixture and the Surrounding Isolation Joint

Figure 6-07: Details for Boxing Out Fixtures