

LOUISIANA DEPARTMENT OF TRANSPORTATION & DEVELOPMENT VERIFICATION PROCEDURE

FLOW METER

EQUIPMENT

1. 0.12 inch Spacer

PROCEDURE

1. Check gage dial for graduation.
2. Check activating pin to be sure it slides with slight amount of frictional resistance.
3. Check movement of the guide sleeve over the guide rod of the breaking head.
4. Check to be sure that the gage dial will adjust to zero.
5. Check dial accuracy by zeroing gage on a flat surface and then placing over a 0.12 inch spacer.