

WATER
DOTD Designation: S 303-99

I. Equipment

- A. One quart plastic sample bottle.
- B. Sampling device (if sample cannot be taken directly with plastic bottle).
- C. MATT forms and envelopes.

II. Water Supply Line

- 1. Allow water to flow for a short time before sample is taken.
- 2. Take sample using the plastic sample bottle.
- 3. Place a properly completed, unsoiled identification form in an envelope and securely attach to the sample container.

III. Lakes, Bayous, Borrow Pits, etc.

- 1. Take samples in the vicinity of the suction inlet to the pump. Do not allow the suction inlet to rest directly on the bottom of the reservoir.
- 2. If the pump is in operation, secure the samples from the discharge end or storage tank.
- 3. Place a properly completed, unsoiled identification form in an envelope and securely attach to the sample container.