# Method of Test for FIBER GLASS ROVING

DOTD Designation: TR 509-93

## Method A - Organic Content

## I. Scope

This method determines the percent organic content.

### II. Apparatus

- A. Muffle furnace capable of maintaining a temperature of  $550 \pm 25$  °C  $(1025 \pm 45$  °F).
- B. **Measuring device** capable of measuring 9 m (30.0 ft).
- C. Desiccator.
- D. Analytical balance 120 g capacity sensitive to 0.0001 g.
- E. Scissors.
- F. Evaporating dish ceramic.
- G. Thermal gloves, apron, tools, eye protection for handling hot materials.
- H. Worksheet Fiber Glass Roving. (Figure 1)

### III. Sample

The sample shall consist of approximately 24 m (75 ft) of fiber glass roving. The test specimen shall consist of approximately 9 m (30.0 ft) of fiber glass roving.

### IV. Health Precautions

Proper equipment and precautions are to be used whenever hot materials or equipment must be handled. Use container holders or gloves while handling hot containers.

### V. Procedure

- A. Measure and cut a test specimen of fiber glass roving 9 m (30.0 ft) in length.
- B. Roll the specimen into a small bundle.
- C. Weigh rolled up specimen on the analytical balance and record weight to the nearest 0.0001 g.
- Place specimen in evaporating dish and place into the muffle furnace set

at  $550 \pm 25$  °C ( $1025 \pm 45$  °F) for a minimum of 15 min.

- E. Remove the dish with specimen from the muffle furnace and allow to cool.
- F. Weigh the dish with specimen and record to the nearest 0.0001 g.

### VI. Calculations

Calculate the % organic content (D) using the following formula:

$$D = \frac{A - B}{\Delta} \times 100$$

where:

A = weight of fiber glass
bundle before ashing, g
B = weight of fiber glass
bundle after ashing, g
100 = constant

example:

A = 
$$22.8291$$
  
B =  $22.6031$   
D =  $\frac{22.8291 - 22.6031}{22.8291} \times 100$   
=  $0.00990 \times 100$   
=  $0.990$   
D =  $1.0\%$ 

### VII. Report

Report the percent organic content to the nearest 0.1 percent.

# VIII. Normal Test Reporting Time

DOTD TR 509-93 Adopted 1/93 Page 2 of 5 Method B

DOTD Designation: TR 509-93

# Method B - Strands per Rove

## I. Scope

This method determines the number of strands per rove in fiber glass roving.

### II. Apparatus

- A. Scissors.
- B. **Measuring device** capable of measuring in cm or in.
- C. Worksheet Fiber Glass Roving. (Figure 1)

## III. Sample

This sample shall consist of approximately 24 m (75 ft) of fiber glass roving. The test specimen shall consist of approximately 10 cm (4 in.) of fiber glass roving.

### IV. Procedure

- A. Measure and cut a test specimen of fiber glass roving approximately 10 cm (4 in.) in length.
- B. Count the number of strands in the specimen.
- Record this number on the worksheet.

# V. Report

Report the number of strands per rove to the nearest whole number.

## VI. Normal Test Reporting Time

DOTD Designation: TR 509-93

# Method C - Yards per Pound of Fiber Glass Roving

# I. Scope

This method of test determines the yards per pound of roving.

# II. Apparatus

- A. **Measuring device** capable of measuring 9 m or 30.0 ft.
- B. Analytical balance 120 g capacity sensitive to 0.0001 g.
- C. Scissors.
- D. Worksheet Fiber Glass Roving. (Figure 1)

# III. Sample

The sample shall consist of approximately 24 m (75 ft) of fiber glass roving. The test specimen shall consist of approximately 9 m (30.0 ft) of fiber glass roving.

### IV. Procedure

- Measure and cut a test specimen of fiber glass roving 9 m (30.0 ft) in length.
- B. Roll the specimen into a small bundle.
- C. Weigh the rolled up specimen on the analytical balance and record weight to the nearest 0.0001 g.

### V. Calculations

Calculate the yards per pound of rove (B)

using the following formula.

$$B = \frac{4536}{A}$$

where:

example:

$$A = 22.8291 g$$

$$B = \frac{4536}{22.8291}$$

$$= 198.69$$

# VI. Report

Report the yards per pound of roving to the nearest yard per pound.

B = 199

# VII. Normal Test Reporting Time

DOTD TR 509-93 Adopted 1/93 Page 4 of 5 Method D

DOTD Designation: TR 509-93

### Method D - Strand Thickness

### I. Scope

This method determines the strand thickness of fiber glass roving.

### II. Apparatus

- A. Scissors.
- B. Micrometer accurate to 0.00001 in.
- Measuring device capable of measuring cm or in.
- D. Worksheet Fiber Glass Roving. (Figure 1)

### III. Sample

The sample shall consist of approximately 24 m (75 ft) of fiber glass roving. The test specimen shall consist of approximately 10 cm (4 in.) of fiber glass roving.

## IV. Procedure

- Measure and cut a test specimen of fiber glass roving 10 cm (4 in.) in length.
- B. Place one strand on the center of the micrometer measurement face.
- C. Close the micrometer until the tension wheel clicks.
- D. Read and record the micrometer reading to the nearest 0.00001 in.
- E. Repeat Steps IV.B.- D. for two more strands.

## V. Report

Report the average of the three readings to the nearest 0.00001 in.

### VI. Normal Test Reporting Time

5/92
Louisiana Department of Transportation and Development Materials Section
Fiber Glass Roving (TR 509)
REMARKS 2
TEST RESULTS P/F (Max. of 15 characters)  STRANDS PER ROVE
YDS./LB. OF ROVE, $(4536 + A)$ $P$
Sample Wt. (A)
TRADE DESIGNATION G (A+B+C) + 3
Measurement A 0.00036 Measurement B 0.00037 Measurement C 0.00038
TRADE DESIGNATION K (A+B+C) + 3
Measurement A Measurement B Measurement C
ORGANIC CONTENT, % [(A-B) + A] x 100
Sample Wt., g. (A)  Sample Wt. After Ashing, g. (B)  Wt. Loss, g. (A-B)  22.829/ 22.803/ 0.2260
Tested By: RA Date: 1/8/93 Checked By: QDB Date: 1/8/93
APPROVED BY: 9. D. Byrd Date: 1/8/93
09 / 4 3 4 -10 5 -10 0 8 7 /128/ 2 2 - 5 7 7 / 13 /N